



RK36SLFS (Sliding shelf for 36" depth DuraRak RK Series Enclosures)

RK42SLFS (Sliding shelf for 42" depth DuraRak RK Series Enclosures)

Installation Instructions

Thank you for purchasing a DuraRak shelf by StarTech.com. These instructions describe how to install the shelf in your rack/enclosure.

1. After removing the packing material, pull the drawer forward so that it is fully extended.
2. Remove the external rail brackets from the drawer by pushing up on the black plastic release tab (visible on the inside brass rail on the drawer when fully extended). When this tab is pushed up, pull the outside bracket off by gently pulling back on the bracket until it is completely disengaged from the drawer. Repeat this process for each side.
3. To affix the rail bracket to the rack, remove the brass insert by removing the three screws holding it in place. Match up the bracket to the location on the rack where you would like to install the drawer (flat edge oriented to the side of the rack). Align the screw hole on the outside of the bracket (identifiable because it is not recessed) to the post at the front of the rack. Match the slot at the back of the bracket to the holes in the post at the rear of the rack.
4. Secure the front and rear of the bracket using screws and nuts provided. Be sure that both are tightly fastened.
5. Re-install the brass insert for the bracket using the original screws.
6. Repeat steps 3, 4, and 5 above for the bracket on the opposite side of the rack.
7. Insert the drawer into the bracket rails until the drawer is fully inserted. The release tab will re-lock to prevent the drawer from accidentally being removed from the rack. Gently pull forward on the drawer until it is fully extended, to verify correct operation.